













629244	1683.1/4		3838909292441	Spare Adapter for 1683/5A	25	Spare parts	15.99 €	JPY 2.900
629245	1683.1/4		3838909292458	Spare Adapter for 1683/5A	25	Spare parts	11.99 €	JPY 2.100
629246	1683.1/4		3838909292465	Spare Adapter for 1683/5A	25	Spare parts	11.99 €	JPY 2.100
629247	1683.1/4		3838909292472	Spare Adapter for 1683/5A	25	Spare parts	10.99 €	JPY 1.900
623256	1689.5		3838909232560	Spare tip for caliper	25	Spare parts	2.99 €	JPY 540
627250	1689.8	M10	3838909272504	Handle for 1689	25	Spare parts	6.99 €	JPY 1.260
627251	1689.8	M12	3838909272511	Handle for 1689	25	Spare parts	10.99 €	JPY 1.900
628959	1693.1Q-SP.1		3838909289594	Set of spare parts for 1693.1Q	25	Spare parts	15.99 €	JPY 2.900
621961	1693.11		3838909219615	Replaceable rubber covers for clamp 1693.1. 2 pcs set	25	Spare parts	27.99 €	JPY 5.000
627266	1693.11	70	3838909272665	Replaceable rubber covers for new clamp 1693.1. 2 pcs set	25	Spare parts	10.99 €	JPY 1.900
623205	1693.12		3838909232058	Accessories for swiveling vice jaw 1693.1 and 1693.1S	25	Spare parts	20.99 €	JPY 3.800
626337	1693.17		3838909263373	Replacement rubber covers for clamp, round, 2 pcs set	25	Spare parts	13.99 €	JPY 2.500
629248	1693.18		3838909292489	QR Lever for 1693A, 1693B, 1693C, 1693R, 1693RP	25	Spare parts	11.99 €	JPY 2.100
629249	1693.19		3838909292496	QR Lever for 1693R, 1693A	25	Spare parts	7.99 €	JPY 1.450
629250	1693.20		3838909292502	Bushing for repair stands for 1693A, 1693B, 1693C, 1693R, 1693RP, 2pcs set	25	Spare parts	4.99 €	JPY 900
629251	1693.21		3838909292519	Adjustable screw for clamp 1693.1 and 1693.1S	25	Spare parts	21.99 €	JPY 3.900
629252	1693.22		3838909292526	Auto-adjust upgrade set for 1693.1S jaw	25	Spare parts	19.99 €	JPY 3.600
629253	1693.23		3838909292533	Adjustable screw for clamp 1693.1 and 1693.1S	25	Spare parts	21.99 €	JPY 3.900
629254	1693.24		3838909292540	Auto-adjust upgrade set for 1693.1S jaw	25	Spare parts	20.99 €	JPY 3.800
629166	1693EL.12		3838909291666	Clamping bracket with handle for clamp for 1693EL	25	Spare parts	50.99 €	JPY 9.200
617824	1694.1	1.1/8"	3838909178240	Head tube reamer	25	Spare parts	199.99 €	JPY 36.200
617310	1697.1	1.3/8x24tpi (BSA)	3838909173108	Taps BSA	25	Spare parts	199.99 €	JPY 36.200
627325	1697.4		3838909273259	Guide for taps 1697.1 in 1698.1	25	Spare parts	44.99 €	JPY 8.100
617590	1699.1	36x24tpi (ITAL)	3838909175904	Taps ITAL	25	Spare parts	199.99 €	JPY 36.200
617592	1699.1	44mm	3838909175928	Bottom bracket reamer	25	Spare parts	139.99 €	JPY 25.400
629234	1700VH		3838909292342	Valve core tool/handle	25	Spare parts	6.99 €	JPY 1.260
628582	1721.1	DUB 29 x 42 (2x)	3838909285825	Bearing press adapter	25	Spare parts	16.99 €	JPY 3.000
625413	1721.1	30 x 42 - BB30 (2x)	3838909254135	Bearing press adapter	25	Spare parts	11.99 €	JPY 2.100
625414	1721.1	24x41-BB86/92 (2x)	3838909254142	Bearing press adapter	25	Spare parts	11.99 €	JPY 2.100
625415	1721.1	22 x 41 (2x)	3838909254159	Bearing press adapter	25	Spare parts	11.99 €	JPY 2.100
625416	1721.1	10 x 26 - 6000	3838909254166	Bearing press adapter	25	Spare parts	4.99 €	JPY 900
625417	1721.1	10 x 22 - 6900	3838909254173	Bearing press adapter	25	Spare parts	3.99 €	JPY 720
625418	1721.1	12 x 28 - 6001	3838909254180	Bearing press adapter	25	Spare parts	3.99 €	JPY 720
625419	1721.1	12 x 24 - 6901	3838909254197	Bearing press adapter	25	Spare parts	3.99 €	JPY 720
625420	1721.1	15 x 28 - 6902	3838909254203	Bearing press adapter	25	Spare parts	5.99 €	JPY 1.080
625421	1721.1	15 x 24 - 6802	3838909254210	Bearing press adapter	25	Spare parts	3.99 €	JPY 720
625422	1721.1	15 x 26 - 1526	3838909254227	Bearing press adapter	25	Spare parts	4.99 €	JPY 900
625423	1721.1	17 x 28 - 17286	3838909254234	Bearing press adapter	25	Spare parts	5.99 €	JPY 1.080
625424	1721.1	17 x 30 - 6903	3838909254241	Bearing press adapter	25	Spare parts	5.99 €	JPY 1.080
625425	1721.1	17 x 26 - 6803	3838909254258	Bearing press adapter	25	Spare parts	4.99 €	JPY 900
625426	1721.1	20 x 32 - 6804	3838909254265	Bearing press adapter	25	Spare parts	5.99 €	JPY 1.080
625427	1721.1	25 x 37 - 6805	3838909254272	Bearing press adapter	25	Spare parts	6.99 €	JPY 1.260
625428	1721.1	x 22.2 (3/8" x 7/8")	3838909254289	Bearing press adapter	25	Spare parts	3.99 €	JPY 720
625429	1721.1	8 x 22 - 608	3838909254296	Bearing press adapter	25	Spare parts	6.99 €	JPY 1.260
625430	1721.2	fi 45	3838909254302	Bearing press protector	25	Spare parts	3.99 €	JPY 720
625431	1721.2	fi 30	3838909254319	Bearing press protector	25	Spare parts	2.99 €	JPY 540
626560	1721.3		3838909265605	Quick slide handle for 1721	25	Spare parts	129.99 €	JPY 23.500
627264	1721.4		3838909272641	Handle with threaded rod for bearing press kit 1721	25	Spare parts	27.99 €	JPY 5.000
627789	1721.5		3838909277892	Threaded shaft	25	Spare parts	13.99 €	JPY 2.500
627252	1722.1		3838909272528	Spindle with pin for 1722/2BI set	25	Spare parts	7.99 €	JPY 1.450
623300	1751.1/7T		3838909233000	Spring for nipple insertion tool	25	Spare parts	12.99 €	JPY 2.300
624212	1752.1		3838909242125	Spring for spoke tension meter	25	Spare parts	5.99 €	JPY 1.080
621020	253.1/4A	2.3 x 2.8	3838909210209	Pin set 2 pieces for 253/2DP	25	Spare parts	8.99 €	JPY 1.630
627824	2650.1/1		3838909278247	Aluminum threaded head for 2650BI	25	Spare parts	10.99 €	JPY 1.900
627825	2650.2/4		3838909278254	Plastic conical head for 2650BI	25	Spare parts	8.99 €	JPY 1.630
623089	689.1/4	6.5 - 8	3838909230894	Arm for 689/2BI	25	Spare parts	34.99 €	JPY 6.300
623090	689.1/4	10 - 12	3838909230900	Arm for 689/2BI	25	Spare parts	34.99 €	JPY 6.300
623091	689.1/4	12 - 15	3838909230917	Arm for 689/2BI	25	Spare parts	35.99 €	JPY 6.500
623092	689.1/4	17 - 20	3838909230924	Arm for 689/2BI	25	Spare parts	47.99 €	JPY 8.700
623093	689.1/4	22 - 28	3838909230931	Arm for 689/2BI	25	Spare parts	57.99 €	JPY 10.500
623094	689.1/4	30 - 36	3838909230948	Arm for 689/2BI	25	Spare parts	76.99 €	JPY 13.900
628671	689.2/2BI-US		3838909286716	Blade with handle for 689/2BI	25	Spare parts	20.99 €	JPY 3.800
625728	689.3/2		3838909257280	Sliding hammer for 689/2BI	25	Spare parts	22.99 €	JPY 4.100
605503	820.1A	22	3838909055039	Spare head for 820A	25	Spare parts	2.99 €	JPY 540
605504	820.1A	27	3838909055046	Spare head for 820A	25	Spare parts	2.99 €	JPY 540
605505	820.1A	32	3838909055053	Spare head for 820A	25	Spare parts	3.99 €	JPY 720
605506	820.1A	40	3838909055060	Spare head for 820A	25	Spare parts	5.99 €	JPY 1.080
605507	820.1A	50	3838909055077	Spare head for 820A	25	Spare parts	7.99 €	JPY 1.450
602530	820.1	22	3838909025308	Spare head for 820	25	Spare parts	2.99 €	JPY 540
602531	820.1	27	3838909025315	Spare head for 820	25	Spare parts	2.99 €	JPY 540
602532	820.1	32	3838909025322	Spare head for 820	25	Spare parts	3.99 €	JPY 720
602533	820.1	40	3838909025339	Spare head for 820	25	Spare parts	5.99 €	JPY 1.080
602534	820.1	50	3838909025346	Spare head for 820	25	Spare parts	6.99 €	JPY 1.300
612503	188.11	1/4"	3838909125039	Set of spare parts for 188.1/1ABI and 188.1/1FBI	25	Spare parts	20.99 €	JPY 3.800
612504	190.11	1/2"	3838909125046	Set of spare parts for 190.1/1ABI and 190.1/1FBI	25	Spare parts	20.99 €	JPY 3.800
612505	238.11	3/8"	3838909125053	Set of spare parts for 238.1/1ABI	25	Spare parts	20.99 €	JPY 3.800